Updating the Magellan eXplorist GC to software version 1.4

This guide will help you upgrade your Magellan eXplorist GC with the most recent software. Go through the checklist to ensure you have everything you need before starting the upgrade process.

- Magellan eXplorist GC
- Computer with the following minimum requirements
    - Pentium or higher processor
    - Internet connection
    - 128 MB RAM
    - USB Port
    - Microsoft® Windows® XP. Vista™ or Windows® 7
    - SVGA (800x600) 16-bit color monitor
- USB cable

The process for you to upgrade the software takes about 20 minutes after downloading the executable (.zip file).

Before starting:

Do not connect your Magellan eXplorist GC to the USB port of your computer until instructed to do so.

1. Close all other applications on your PC. This includes virus checkers and applications that are running in your system tray. This will enable the upgrade process to run more smoothly and efficiently.
2. Do not connect your Magellan eXplorist GC to your PC until instructed to do so by the Update Wizard.
3. The Update must be completely downloaded and run from hard drive of your PC.
4. Install fresh AA batteries or, if using rechargeable batteries, make sure that they are fully charged before beginning.

Update process. Please print these instructions:

1. Double click the installer executable (eXploristGC_1_4_Rel1) file that was downloaded from www.magellangps.com. This file is a self-extracting executable which will first unzip the files and begin the update automatically.

2. Click Next on the Welcome screen:

3. Read the Attention screen and press Next.

Magellan Update Wizard 4.7.4.1

Unit Connection

MAGELLAN®

1. Turn on your GPS receiver.

2. Allow the GPS receiver to completed restart.

3. Once the Main Menu is displayed, connect your GPS receiver to your computer using the provided USB cable.

4. If prompted, please select 'Connect to PC' on the device.

5. Wait for the screen to display "USB connected" or 'Connected to PC' and the GPS receiver to be recognized as a removable drive on your PC.

6. Click 'Next'.

Press 'Cancel' to exit without updating.

If you are having trouble connecting the GPS receiver to your PC, please contact Magellan Support pages at http://www.magellangps.com/support

< Back   Next >   Cancel

4. Power on your Magellan eXplorist GC and wait for the receiver to display the Main Menu.

5. Connect the Magellan eXplorist GC to your computer using the USB cable.

   a) **Please NOTE:** if the Microsoft® 'Found New Hardware Wizard' appears, select cancel.

   b) If the "Windows Signature" window appears, press the 'Continue' button

6. When prompted, select "Connect to PC" on your Magellan eXplorist GC.

7. Click Next>. The update process will begin. Progress bars are displayed showing the progress of the update. Do not power off your Magellan eXplorist GC. Do not disconnect the USB cable during the update process.

8. The updater will indicate that the transfer of files was successful.

9. Remove the USB cable.

10. The Magellan eXplorist GC will begin installing the files. Do not disturb the device during this process.

11. The Magellan eXplorist GC will restart automatically to complete the update process. Do not press any buttons.

12. When the Main Menu is displayed the Magellan eXplorist GC has been updated to the latest software.

13. Press 'Finish' on your PC to exit the Update Wizard.

** If the update fails for any reason, check the minimum system requirements and try running the update wizard again before contacting Technical Support (www.magellanGPS.com/support) **