

Setup the Triton for First-Time Use

APPLICATION NOTES
T-102

There are three User Profiles available (Hiking, Marine, and Geocaching) that you can customize for your personal use. These settings can be accessed and customized by selecting the Profiles option under the View menu.

Because of the Triton's advanced GPS technology and highly sensitive antenna, no initialization process is needed. We do, however, recommend that you perform the following steps prior to first time use:

Display Options

Backlight Level	Off, Low, Medium, High	Decreasing backlight levels will increase battery life.
Backlight Timer	Off, 15 sec, 30 sec, 60 sec	Sets duration of no GPS or screen activity before the backlight turns off.
Power Off Timer	Off, 5 min, 15 min, 60 min	Sets duration of no GPS or screen activity before the receiver turns off in sleep mode.
Time Format	12-hour or 24-hour	
Time Zone	Select zone	
Daylight Savings	On or Off	
Language	English or French	

Map Options

Map Detail	Low, Medium, High	
Waypoint Names	On or Off	Displays waypoint names on the map screen.
Geocache Icons	Not Found, All, Off	Displays geocache waypoint icons on the map screen.
Place Names	On or Off	Displays names of waypoints stored in the receiver as places.
Trail Lines	On or Off	Display of trail (track) lines on the map screen.
Orientation	North, Course, Track	Sets orientation for the top of the display.
Position Destination Line	On or Off	Display of the Line of Sight (LOS) line from your current position to your destination.
Places Shown	List of possible places	Select from list of places which ones are to be displayed on the map screen.

Alert Options


GPS Fix	On or Off	
Alarm Tone	Beep or Ring	
Alarm Volume	Off, Low, Medium, High	
Beeper Volume	Off, Low, Medium, High	
Beeper Mode	Keys, Alarms, Keys & Alarms, Off	
Anchor	Off, 1 mi., 0.5 mi.	
Off Course	Off, 10 ft., 20 ft.	
Arrival	On or Off	
Waypoint Proximity	Off, 1 mi., 0.5 mi.	
Geocache Proximity	Off, 1 mi., 0.5 mi.	
Low Battery	On or Off	

To change the Settings, follow steps below


1. From the Map screen, press **Menu**, then select **View** and press **Enter** (The Enter key is the center button on Up/Down keypad).



2. As a result you will see the screen to the right. Select **Profiles** and press **Enter**.



3. Under Profiles there are three pre-named User Profiles to choose from. We will use **Hiking** for this example. Select **Hiking** and press **Enter**.



4. Press the **Page/GOTO** button to access the pages where changes can be made.




5. The first screen is the **Display** settings page. You can make Power and Display adjustments on this page by using the Up/Down keypad.



6. Press the **Page/GOTO** key once again to bring up the Map Display options. Select and set each of the screen items.



7. Press the **Page/GOTO** key again to access the Alarm Settings.



8. After you selections have been made, press the **Page/GOTO** key and you will see the screen to the right. Then press **Enter** to activate the profile. Press the **Esc** key repeatedly to return to the map screen.




How to Connect Your Triton GPS to VantagePoint Application Software

Before connecting your Triton GPS receiver to VantagePoint on your PC, perform the following steps on your GPS receiver:

1. From the Map screen, press **Menu**.



2. Select **View** on the Menu screen and press **Enter**.
3. Select **Settings** from the View Menu and press **Enter**.



4. Select **Connectivity** from the settings screen and press **Enter**.
5. Select **VantagePoint** from the drop-down screen and press **Enter**.
6. Press **Escape** repeatedly until you reach the Map screen.
7. Connect your USB Cable from the GPS to the PC.

